



# Configurar comando

Configure remote



# Programação Motor bateria Edison B3 Came

O motor deve ser carregado por 6 horas antes do primeiro uso  
The engine must be charged for 6 hours before first use

- 1** Ligar Botão preto na lateral do motor e deixar fazer 3 movimentos sonoros. A seguir carregar no botão branco do motor. (acabou de abrir a programação do motor)

Turn on the black button on the side of the motor and let it make 3 beeps. Then press the white button on the motor. (you have just opened the motor programming)

- 2** Carregar 2x no botão p2 (parte de tras do comando) + botão subida  
Carregar 2x no botão p2 (parte de tras do comando) + botão descida  
Press 2x the p2 button (back of the controller) + up button  
Press 2x the p2 button (back of the controller) + down button

- 3** Carregar em p2 + up + p2. O motor vai fazer um sinal sonoro, depois coloque o estore na posição pretendida (todo aberto) e carregue na tecla STOP e vai ouvir novo sinal sonoro

Press p2 + up + p2. The engine will beep, then place the blind in the desired position (open) and press the STOP button and you will hear a new beep

- 4** Repetir o procedimento para fim de curso superior e clicar STOP até ouvir sinal sonoro

Repeat the procedure for the upper limit switch and click STOP until hear beep

#### RESET:

Manter pressionado o botão de programação na cabeça do motor até ouvir 3 sinais sonoros

Press and hold the programming button on the motor head until you hear 3 beeps